

How to determine if a gasoline-powered vehicle has on-board refueling vapor recovery (ORVR)

Vehicle Class	Non-ORVR Vehicles	ORVR Phase-in Model Years (Transition Years)	ORVR model years
<p>Passenger Cars: Check the model year and vehicle class on the emission label (tune-up label) in the engine compartment. Look for an indication that the vehicle is a passenger car or "PC" or "LDV."</p>	<p>If the model year is 1997 or older, it is non-ORVR.</p>	<p>1998, 1999: Check the emission label (tune-up label) in the engine compartment. If the evaporative family code has an "R" as the fifth character in the sequence, it is ORVR compliant. If the evaporative family code contains any other character as the fifth character in the sequence, it is not ORVR compliant, and may be presumed to be non-ORVR.</p>	<p>If the vehicle is a model year 2000 or newer year passenger car (PC), it is ORVR</p>
<p>Light Duty Trucks: Check the vehicle weight inside the driver's door frame. If the gross vehicle weight rating (GVWR) is 6000 lbs. or less, then the vehicle is a light-duty truck and may be subject to the ORVR requirements. Check the emission label (tune-up label) in the engine compartment for indication of the model year and confirm that the vehicle is a light-duty truck or "LDT."</p>	<p>If the model year is 2000 or older, it is non-ORVR.</p>	<p>2001, 2002: Check the emission label (tune-up label) in the engine compartment. If the evaporative family code has an "R" as the fifth character in the sequence, it is ORVR compliant. If the evaporative family code contains any other character as the fifth character in the sequence, it is not ORVR compliant, and may be presumed to be non-ORVR.</p>	<p>If the vehicle is a model year 2003 or newer year light-duty truck (LDT), it is ORVR.</p>
<p>Light Duty Trucks / Medium-Duty Vehicles: Check the vehicle weight inside the driver's door frame. If the gross vehicle weight rating (GVWR) is greater than 6000 lbs., the vehicle may be a light-duty truck or medium-duty vehicle subject to the ORVR requirements. Check the emission label (tune-up label) in the engine compartment for indication of the model year and confirm that the vehicle is a light-duty truck or "LDT" or medium-duty vehicle or "MDV."</p>	<p>If the model year is 2003 or older, it is non-ORVR.</p>	<p>2004, 2005: Check the emission label (tune-up label) in the engine compartment. If the evaporative family code has an "R" as the fifth character in the sequence, it is ORVR compliant. If the evaporative family code contains any other character as the fifth character in the sequence, it is not ORVR compliant, and may be presumed to be non-ORVR.</p>	<ul style="list-style-type: none"> • If the vehicle is a light-duty truck (LDT) or medium-duty vehicle (MDV) between 6000 and 8500 lbs. GVWR, and it is 2006 model year or newer, it is ORVR compliant. • If the vehicle is a medium-duty vehicle (MDV) between 8500 and 10000 lbs. GVWR, and it is 2006 model year or newer, the emission label (tune-up label) should be checked. If the evaporative family code has an "R" as the fifth character in the sequence, it is ORVR compliant. If the evaporative family code does not have an "R" as the fifth character in the sequence, it is not ORVR compliant. • If the vehicle is a medium-duty vehicle (MDV) greater than 10000 lbs. GVWR, it is not ORVR compliant.